

'Jenny Twin' Slate Repair Fixings

The invisible repair system, mechanically re-fixes natural roofing slate.



Before Repair...



Repairs carried-out with 'Jenny Twin' system.

FITTING INSTRUCTIONS

Stage 1



Insert the swivelled tail into the recessed groove on the underside of the main body of the clip.

Drill or punch a hole to each side of the slate above existing or normal holing gauge (equal to approx. half batten width +5mm) and approx. 50mm from the side.

Fit clip by bending tongue down and pushing through the hole in the slate and bottom leg of the clip. Pull tongue through with pliers or similar until fitting tightly; bend tongue back to secure.

Fix one clip to either side of the slate, ensuring swivelled tail is on the underside of the slate. If slates to be repaired are butt jointed it will be necessary to nibble 2-3mm from the side of each slate where the clip is to be fitted. This will allow the clip to be located within the overall dimensions of the slate.

Stage 2



Lay slate flat on roof and push into position. The use of a slate ripper may assist in guiding the head of the slate being repaired onto the support batten.

Once the tail of the slate is in alignment with other slates in the course, the swivelled tail will automatically drop into place behind the batten.

